



## Bluetooth Headset<sup>KYO110</sup> QuickStart Guide

A complete user guide can be found at <http://www.kyocera-wireless.com/support>.

82-R2010-1ES, Rev. 001

### GETTING TO KNOW YOUR BLUETOOTH HEADSET<sup>KYO110</sup>

1	AC Charger Jack	
2	Earhook	
3	Multi Function Button / LED Indicator	
4	Microphone	
5	Volume Adjust Button	
6	Earpiece	
<b>Kit Contents:</b> Bluetooth Headset <sup>KYO110</sup> , AC Charger, Quick Start Guide, and Warranty Card.		

### CHARGING THE BATTERY

**Note:** The battery must be charged for at least 2 hours prior to use. Once charged, it provides up to 6 hours of talk time. A tone will sound when the battery is low.

- Insert one end of the AC Charger into the **AC Charger Jack** on your headset.
- Plug the opposite end of the AC Charger into a wall outlet.  
**Note:** The **LED Indicator** will illuminate red while the headset is charging, and turn off when charging is complete.
- Unplug the AC Charger from the headset when charging is complete.

### PAIRING THE HEADSET WITH YOUR CELL PHONE

**Note:** Ensure your headset is powered off, and your cell phone is powered on.

- Press and hold the **Multi Function Button** for 6 seconds until the **LED Indicator** flashes red and blue. A tone will sound indicating your headset is in pairing mode.
- Activate the Bluetooth connection from your cell phone. Execute the search function to search for Bluetooth devices. When the search completes, a list of supported devices will be displayed on your cell phone screen.  
**Note:** The headset will not be detected unless first placed in pairing mode.

- To start the pairing process, select **KYO110** from the device list.
- When prompted select **0000** as the passkey.

**Note:** Depending on your cell phone, pairing operations may execute automatically. Please consult your phone user guide if specific pairing operations are needed.

### PERFORMING BASIC FUNCTIONS

#### POWER ON

Press the **Multi Function Button** for 4 seconds. The **LED Indicator** will flash blue.

#### POWER OFF

Press the **Multi Function Button** for 5 seconds. The **LED Indicator** will flash red.

#### VOLUME ADJUST

Press the **Volume Adjust Button** up or down to increase or decrease call volume.

#### ANSWER A CALL / END A CALL

Press the **Multi Function Button**.

#### REJECT AN INCOMING CALL

Press and hold the **Multi Function Button** for 3 seconds.

#### TRANSFER A CALL (headset to cell phone / cell phone to headset)

Press the **Multi Function Button** for 3 seconds.

#### REDIAL LAST NUMBER

Press the **Multi Function Button** 2 times. A high tone will sound once a connection is established.

#### VOICE DIALING (phone dependant feature)

To activate voice dialing, press and hold the **Multi Function Button** for 3 seconds. To cancel voice dialing, press and hold the **Multi Function Button** for 3 seconds.

**Note:** Review your cell phone user guide for detailed voice dialing instructions.

#### FCC NOTICE

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### CAUTION

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the warranty and users' authority to operate the equipment.

#### NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

#### FCC RADIATION EXPOSURE STATEMENT

To comply with the FCC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or transmitter.



## Guía de inicio rápido del Auricular Bluetooth<sup>KYO110</sup>

Podrá encontrar una guía del usuario completa en <http://www.kyocera-wireless.com/support>.

82-R2010-1ES, Rev. 001

### ASPECTOS BÁSICOS DEL AURICULAR BLUETOOTH<sup>KYO110</sup>

1	Conector para Cargador de CA	
2	Gancho para el auricular	
3	Botón DE Función múltiple / Indicador luminoso LED	
4	Micrófono	
5	Botón de Ajuste de volumen	
6	Audífono	
<b>Contenido del kit:</b> Auricular Bluetooth <sup>KYO110</sup> , Cargador de CA, guía de inicio rápido, y tarjeta de garantía.		

### CÓMO CARGAR LA BATERÍA

**Nota:** La batería debe cargarse durante 2 horas como mínimo. Una vez cargada, proporciona hasta 6 horas de tiempo de conversación. Un sonido le indicará cuando la batería esté baja.

- Introduzca uno de los extremos del Cargador de CA en el **conector para Cargador de CA** del auricular.
- Conecte el otro extremo del Cargador de CA a una toma de corriente de pared.
 

**Nota:** El **indicador luminoso LED** emitirá una luz de color rojo cuando el auricular se esté cargando. Esta luz se apagará cuando haya finalizado el proceso de carga.
- Desconecte el Cargador de CA del auricular cuando haya finalizado el proceso de carga.

### CÓMO SINCRONIZAR EL AURICULAR CON EL TELÉFONO CELULAR

**Nota:** Asegúrese de que el auricular esté apagado y el teléfono celular esté encendido.

- Mantenga presionado el **botón de Función múltiple** durante 6 segundos hasta que el **indicador luminoso LED** titile con una luz de color rojo y azul. Un sonido le indicará que el auricular está en modo de sincronización.

- Active la conexión Bluetooth del teléfono celular. Utilice la función de búsqueda para buscar dispositivos Bluetooth. Una vez que haya finalizado la búsqueda, aparecerá una lista de dispositivos compatibles en la pantalla del teléfono celular.
 

**Nota:** Si el auricular no se encuentra en modo de sincronización, no podrá detectarse.

- Para iniciar el proceso de sincronización, seleccione **KYO110** de la lista de dispositivos.
- Cuando se le indique, seleccione **0000** como contraseña.

**Nota:** Según el teléfono celular, es posible que las tareas de sincronización se realicen automáticamente. Si desea obtener información adicional acerca de tareas de sincronización, consulte la guía del usuario del teléfono.

### CÓMO UTILIZAR LAS FUNCIONES BÁSICAS

#### ENCENDER

Presione el **botón de Función múltiple** durante 4 segundos. El indicador luminoso LED titilará con una luz azul.

#### APAGAR

Presione el **botón de Función múltiple** durante 5 segundos. El **indicador luminoso LED** titilará con una luz roja.

#### AJUSTAR EL VOLUMEN

Presione la parte superior o inferior del **botón de Ajuste de volumen** para subir o bajar el volumen.

#### RESPONDER UNA LLAMADA / FINALIZAR UNA LLAMADA

Presione el **botón de Función múltiple**.

#### CÓMO RECHAZAR UNA LLAMADA ENTRANTE

Mantenga presionado el **botón de Función múltiple** durante 3 segundos.

#### TRANSFERIR UNA LLAMADA

(del auricular al teléfono celular/ del teléfono celular al auricular)  
Presione el **botón de Función múltiple** durante 3 segundos.

#### VOLVER A MARCAR EL ÚLTIMO NÚMERO AL QUE SE LLAMÓ

Presione el **botón de Función múltiple** 2 veces. Un sonido elevado le indicará que se ha establecido la conexión.

#### MARCACIÓN POR VOZ (esta función depende del teléfono)

Para activar la marcación por voz, mantenga presionado el **botón de Función múltiple** durante 3 segundos. Para desactivar la marcación por voz, mantenga presionado el **botón de Función múltiple** durante 3 segundos.

**Nota:** Para obtener instrucciones detalladas acerca de la marcación por voz, consulte la guía del usuario del teléfono celular.