



C5121 Milano

USB Installation Guide

Introduction

These instructions explain how to install USB drivers that enable the device to be used as a modem (tethered).

Windows Vista / Windows 7 Install

1. Make sure the device is NOT connected to the PC.
2. Go to the <http://www.kyocera-wireless.com/> Web site.
3. Click the **Support** link.
4. Click the **Phone Drivers** tab.
5. Click the **sy31_setup.msi** file to launch the install wizard.
6. Complete the install wizard to install the USB modem driver.
7. Click the **sy31_adb_setup_x86.msi** file (for 32 bit operating systems) or **sy31_adb_setup_x64.msi** file (for 64 bit operating systems) to launch the install wizard.
8. Complete the install wizard to install the ADB driver.

Windows XP Install

1. Make sure the device is NOT connected to the PC.
2. Go to the <http://www.kyocera-wireless.com/> Web site.
3. Click the **Support** link.
4. Click the **Phone Drivers** tab.
5. Click the **sy31_setup.msi** file to launch the install wizard.
6. Complete the install wizard to install the USB modem driver.
7. Click the **sy31_adb_setup_x86.msi** file to launch the install wizard.
8. Complete the install wizard to install the ADB driver.
9. Click the **sy31_ndis_setup_x86.msi** file to launch the install wizard.
10. Complete the install wizard to install the NDIS driver.

Tether Device to PC

1. Connect the device to the PC with the USB cable.
2. Touch **Tethered mode**.
3. Touch **Done** to enable data networking.